

## **mumbi Smoke detector magnetic fixing / m-RMAG**

User manual



GB




Claus GmbH  
Sigsfeldstr. 4  
45141 Essen

[www.mumbi.de](http://www.mumbi.de)

# User Manual


## m-RMAG — Smoke detector magnetic fixing


 Please refer to the respective manual for the installation and commissioning of the smoke detector.

Carrier plate for  
ceiling suspension


Magnetic plate  
for smoke detector  
assembly


GB

-  Take the carrier plate and remove the protective sheet.

**Hint** For an easier detachment, an acute object such as a knife or a pin is suitable. 

- Place the carrier plate at the intended position on the ceiling.
- Take the carrier plate, remove the protective sheet as well and place it on the back of the smoke detector.
- Mount the smoke detector after 24 hours on the ceiling, by putting the magnetic plate on the carrier plate. Please pay attention that all magnets are in contact to ensure a secure mounting.

-  In Order to remove the smoke detector from the ceiling, just push it across the ceiling from the carrier plate.

 For security reasons please do not reuse this product.

This magnetic fixing is only suitable for smoke detectors with a cross-section dimension of 8-15cm and a maximum weight of 275g. Please use the magnetic fixing only on a plain surface. Place the fixing on the ceiling and the smoke detector. Wait 24 hours before you bring both parts together.

Not suitable for vinyl wallpapers, styrofoam®, siliconized, nonstick or teflon covered surfaces.